

WELCOME PARENTS

CASUALPLAY thank you for the confidence you have placed in us by purchasing this safety seat. This product has been designed, manufactured and accredited under the strictest safety regulations. We have thought about its ease of installation and use, but we need you to install it correctly for optimal operating results. Please read these instructions carefully before installing the seat in your car. The safety of your child depends on you using it correctly. Do not hesitate to contact us if you have any queries (Tel., e-mail, see the back of these instructions)

GET TO KNOW THE FIX PROTECTOR



1. Regulator knob (dual function)
2. Function selector:
 - Lengthening seat
 - Back recline
3. Arm rest strap runner
4. Seat
5. Seat back
6. Headrest
7. Headrest strap runner
8. Arm rest
9. ISOFIX Connectors
10. Connector unlocking button

11. Buttons (both sides) to adjust the connector length
12. Diagram of belt path
13. Button to separate seat/back sections
14. Official approval badge
15. Attachment clip
16. Instructions booklet
17. Headrest extension handle
18. Headrest adjustment button
19. Folding connector button

WARNING

1. This is a "UNIVERSAL" retention system. It is certified under Regulation n°44, amendments series 04, for general use in vehicles and appropriate for the majority of car seats although not all.
2. Correct installation is required if the vehicle manufacturer has stated in the instructions manual that the vehicle is suitable for a "UNIVERSAL" retention system for this age group to be installed.
3. This retention system has been classified as "UNIVERSAL" according to stricter conditions than those that are applied to previous designs that do not carry this warning.
4. If you have any queries contact the seat manufacturer or retailer.

WARNINGS AND SAFETY INFORMATION

THIS INSTRUCTION MANUAL MUST BE KEPT INSIDE THE PROTECTOR FIX DURING USE.

READ THESE INSTRUCTIONS CAREFULLY BEFORE USING THE DEVICE AND KEEP THEM FOR FUTURE REFERRAL. YOUR CHILD'S SAFETY MAY BE AFFECTED IF THESE INSTRUCTIONS ARE NOT FOLLOWED.

- The **PROTECTOR FIX** is a child seat belonging to Group 2-3 (15 - 36 kg.).
- The seat should be fastened onto the car seat using the 3-point seat belt with or without the retractor of the actual vehicle, certified in under the UN/ECE 16 Regulations or equivalent standards and by means of the ISOFIX connectors if it is fitted with the fasteners.
- The original equipment must not be modified.
- After any accident, the seat must be checked or changed.
- Protect any part of the seat from possible damage caused by a folding car seat or a vehicle door.
- Protect all metallic parts in contact with the child from the sun's heat.
- The straps must never be twisted.
- Use the seat for every journey, no matter how short, and never leave the child alone inside the vehicle.
- The safety seat should be secured with the 3-point seat belt or with the ISOFIX connectors if the fasteners are fitted even if the child is not travelling in it, if not it should be removed from the vehicle.
- It is recommended that any luggage or other objects that can cause injuries in a collision are made safe or securely fastened.
- We guarantee the safety of the device when it is used by the first-time buyer.
- We advise against using second-hand products for safety purposes.
- Be extremely careful when installing the child safety seat, since installing it correctly can save the life of your child if you have an accident (follow the manufacturer's instructions correctly).
- It is important that the rest of the passengers in the vehicle are also strapped in with a seat belt. If not, they can be thrown around in an accident and damage the baby.

- Check the different parts of the seat regularly.
- The seat should not be used without its cover.
- Only the cover supplied by the seat manufacturer should be used, as it is an important part of the product.
- You are responsible for the child's safety.
- The upholstery should be hand washed, using mild soap and warm water; or machine washed at a maximum temperature of 30° C and **WITHOUT SPINNING**. Do not use chemical cleaners (dry-cleaning).

GENERAL INSTRUCTIONS

PROTECTOR FIX Assembly (see illustrations 01 - 04)

- The **PROTECTOR FIX** arrives disassembled for easier transport (fig. 01)
- Position the back so that the clamp is between the metallic structure of the **PROTECTOR FIX** base (fig. 02 - 03), never behind it (fig. 04). A "characteristic click" confirms that the attachment has been made successfully.

WARNING: Never use **PROTECTOR FIX** without the back section as it has been accredited as a unit. Using it without the back section will affect the health of the child.

PROTECTOR FIX Installation inside the car (see illustrations 05 - 12)

- **PROTECTOR FIX** must be installed in the back seat of the vehicle with a three point seat belt and the ISOFIX connectors.
- Remove the headrest from the seat where you are going to install the seat (fig. 05).
- Position the clips in front of both ISOFIX slots, which are situated between the seat and the backrest (fig. 06).

NOTE: if the vehicle came supplied with these connectors, it is not necessary to assemble them.

- Next press either the left or right button (fig. 07) and, while keeping it pressed down, extend the length of the connector bars (fig. 08).
- Put the **PROTECTOR FIX** in the back seat of the car (fig. 09) in front of the ISOFIX hooks.
- Push the safety seat with both hands in the direction towards the anchorages until a "click" tells you that the attachment on both sides has been made (fig. 10).
- Check the correct installation of the system, by verifying that a green line appears on the upper part of the connector unlocking devices (fig. 11). If a red line appears in one of the connectors, it indicates that it is not correctly attached. Re-start the operation.
- Finally, adjust the free play between the **PROTECTOR FIX** and the back of the car by pressing either of the side buttons on the base, and pushing the safety seat firmly towards

the back of the car (fig. 12).

Place the child in the PROTECTOR FX seat (see illustrations 14 - 17)

- Adjust the headrest to its maximum height (fig. 14 - 15) and pass the diagonal part of the belt through the headrest runner. Re-adjust the headrest to the appropriate position for the height of the child.
- Fasten the seat belt by passing it over the **PROTECTOR FIX** so that the lap strap is as low as possible and the diagonal strap holds the child firmly (fig. 16).
- Fasten the belt and check that the lap strap is underneath both arm rests (area marked in red) and the diagonal strap is above the arm rest next to the buckle (fig. 17). Adjust the height of the headrest so that the diagonal strap of the car seat belt passes over the chest of the child and not across his/her neck.

Adjusting the PROTECTOR FX height (see illustrations 18 - 19)

- The **PROTECTOR FIX** is height adjustable to adapt to the growth of the child (fig. 18). Once it is fitted in the car with the child, adjust the height of the **PROTECTOR FIX** so that the belt never goes across the child's neck.
- Press the button behind the top of the headrest to adjust its height (fig. 19).

Adjusting the PROTECTOR FX base (see illustrations 20 - 21)

- The base of the **PROTECTOR FIX** is adjustable according to the growth of the child.
- When seated inside, adjust the base according to the length of the child's legs.
- Turn the selector knob to the left (fig. 20) and move to modify the length of the base according to the legs of the child (fig. 21).

Adjusting the PROTECTOR FX recline (see illustrations 22 - 23)

- The back of the **PROTECTOR FIX** has a reclining adjustment to suit the requirements of the moment. If the child falls asleep or wants to adopt a more relaxed position, increase the recline of the **PROTECTOR FIX** seat.
- Turn the selector knob towards the right (fig. 22) and move the seat towards the desired position (fig. 23).

Removing the PROTECTOR FX from the car (see illustration 24)

- Release the seat belt buckle in the vehicle, loosen it and remove it from the runner.
- Remove the child from the **PROTECTOR FIX** seat.
- Release the connectors on both sides (a red signal will appear) (fig. 24).
- Detach the safety seat from the car seat.

Dismantling the PROTECTOR FX (see illustrations 25 - 26)

- To dismantle the **PROTECTOR FIX** seat, press the button located on the lower part of the back section (fig. 25) and pull the back section away from the seat section (fig. 26).

PROTECTOR FX connectors folding mechanism (see illustrations 27 - 28)

- While pressing the ridged part of the red button, lift it up slightly to release the mechanism and maintaining the pressure (fig. 27), turn either of the 2 connectors downwards.
- Release the button and continue turning (fig. 28). When the connectors reach the maximum folding position (180 °), the mechanism will click indicating that it is locked again.
- To unfold the connectors, repeat the process until it clicks again indicating that it is locked into place.

Removing and replacing the upholstery (see illustrations 29 - 30)

- Take the backrest off the base.
- For the upholstery on the backrest, unfasten the zips, undo the fastening straps and the plastic strips (fig. 29).
- For the upholstery on the base, undo the fastening straps underneath the base (fig. 30).
- Follow the same steps in reverse order to put the upholstery back on again.